

Ethisis license levels version 12.0.0.3

Ethisis Server

License level	<i>Free</i>	<i>Basic</i>	<i>Extended</i>	<i>Advanced</i>	<i>Premium</i>
Number of cameras ¹	4	1-20	1-40	1-64	1-250
Max storage capacity	Unlimited	Unlimited	Unlimited	Unlimited	Unlimited
Max storage time	1 day	Unlimited	Unlimited	Unlimited	Unlimited
Number of concur. clients conn. to server (the sum of clients, ActX, Ethisis Mobile & WQ) ¹	2	3	5	20	Unlimited
Requires Internet connection	Yes	No	No	No	No
Schedules	•	•	•	•	•
Recording on event and continuous recording	•	•	•	•	•
Motion detection	•	•	•	•	•
Centralized administration	•	•	•	•	•
Browsing for cameras on the network	•	•	•	•	•
Script engine	•	•	•	•	•
Data logging	•	•	•	•	•
PTZ	•	•	•	•	•
Camera groups	•	•	•	•	•
Virtual cameras	•	•	•	•	•
I/O devices (1 device / camera license)	•	•	•	•	•
Connect Ethisis Mobile – Light mode	•	•	•	•	•
Connect Ethisis Mobile – Full mode	-	•	•	•	•
E-mail/SMS	-	•	•	•	•
OPC-client	-	-	•	•	•
Signing of exported jpg images	-	-	•	•	•
Multiple streams from cameras ²	-	-	•	•	•
Door controllers (1 door / camera license)	-	-	•	•	•
Audio out to cameras	-	-	•	•	•
Audio out to audio devices (1 device / camera license)	-	-	•	•	•
Number of I/O signals via external OPC-server	-	-	32	128	Unlimited
Number of preset positions/camera	-	-	Unlimited	Unlimited	Unlimited
Number of guarded tours/camera	-	-	Unlimited	Unlimited	Unlimited
TCP/http listeners	-	-	Unlimited	Unlimited	Unlimited
Connect Ethisis Server OPC-server	-	-	Option	Option	•
Connect ActiveX client	-	-	Option	Option	•
Connect WideQuick EthisisView	-	-	-	Option	•
Multiple storage devices	-	-	-	•	•
Authorization	-	-	-	•	•
Possibility of pre authorization	-	-	-	•	•
Ethisis native users and user groups	-	-	-	•	•
Audit trail	-	-	-	•	•
Remote control of Ethisis Client via script	-	-	-	•	•
Dewarping of 360-cameras in Admin/Client	-	-	-	•	•
Support for UPS	-	-	-	•	•
Hardware acceleration	-	-	-	•	•
Audio in from cameras	-	-	-	•	•
Recording of audio from cameras	-	-	-	•	•
Mini Player	-	-	-	•	•
Support for GigE cameras	-	-	-	-	•
Floating camera licenses	-	-	-	-	•
Encryption of video and data storage	-	-	-	-	•
Support for cluster and redundancy	-	-	-	-	•
Support for database connections	-	-	-	-	•
Support for alarm central functions	-	-	-	-	•
Alarm operator functions	-	-	-	-	Option
.Net script plugins	-	-	-	-	Option

¹ The current hardware of the server/network may limit the actual number of cameras/clients that can be connected. It is up to the integrator to ascertain that the offered hardware can handle the proposed plant.

² Maximum total number of video streams is 2 x the number of available camera licenses.

Ethisis license levels version 12.0.0.3

Ethisis Client³

Connected server's license level	Free	Basic - Premium
Number of servers a client can connect to	1	Unlimited
Number of camera views/client view ⁴	64	64
Number of sections	Unlimited	Unlimited
Support for megapixel cameras	•	•
Hotspot	•	•
Automatic camera switching	•	•
Support for maps and pictures in camera views	•	•
Export of recorded video	•	•
Motion search in recorded video	•	•
Digital zooming	•	•
Remote control of client from external system via COM	•	•
Client view activation via I/O	•	•
PTZ	•	•
Support for joystick	•	•
Event triggered playback of sound files	•	•
Authorization ⁵	•	•
Audit trail ⁵	•	•
Support for multiple monitors	•	•
Interaction objects in camera views	•	•
No license required	•	•
Wide screen support (flexible client views)	•	•
Event list	•	•
Alarm list	•	•
Pre authorization ⁵	•	•
Instant replay	•	•
Virtual cameras	•	•
Dewarping of 360-cameras ⁵	-	•
Connect to cluster	-	•
Hardware acceleration ⁵	-	•
Mini Player ⁵	-	•

³ Ethisis Client is free of charge and exists only in one version. Availability of functions can depend on license level of Ethisis Server.

⁴ The current hardware of the computer/network may limit the actual number of cameras that can be displayed. It is up to the integrator to ascertain that the offered hardware can handle the intended function.

⁵ Availability of function depends on current license level of Ethisis Server.